



Product size:1000*1000mm



1




LED light bar assembly x 1

2




Corner x 4

3




Upright plate with integrated power x 1

4




Right side upright plate x 1

5




Countertop panel assembly x 1

6




Shelf board x 1

7




Right door panel x 1

8



Left door panel x 1

9



Power cable x 1



10



Reset pin x 1



Step 1

Step 3




Step 2


Step 4




Step 5




Step 6




Step 7




Step 8



Step 9



Step 10



Fingerprint settings & Unlock step

I. The smart fingerprint lock can register a total of 10 fingerprints.

II. Short press the reset hole with the reset pin once, the blue light will stay on, place your finger on the fingerprint recognition window within 3 seconds, the flashing blue light indicates successful recognition.

III. Place the same fingerprint for five times. The blue light staying on for 2 seconds indicates successful registration. Flashing red light indicates registration failure; repeat the above steps to register again.

IV. Please repeat the above steps to register the second fingerprint.

V. Press and hold the reset hole with the pointer for more than 5 seconds. The blue light flash 5 times, indicating that all fingerprints cleared.

VI. Touch the fingerprint recognition area, the blue light will turn on and vibration will indicate success, once the fingerprint is recognized, the lock can be opened.

