



Product size:1000\*1000mm



①




LED light bar assembly x 1

②




Corner x 4

③



Left side upright plate x 1

④




Right side upright plate x 1

⑤




Countertop panel assembly x 1

⑥




Shelf board x 1

⑦




Right door panel x 1

⑧




Left door panel x 1

⑨



Power cable x 1



⑩



Reset pin x 1



Step 1

Step 3




Step 2


Step 4




Step 5




Step 6




Step 7




Step 8



## Step 9



## Step 10



---

## Fingerprint settings & Unlock step

**I.** The smart fingerprint lock can register a total of 10 fingerprints.

**II.** Short press the reset hole with the reset pin once, the blue light will stay on, place your finger on the fingerprint recognition window within 3 seconds, the flashing blue light indicates successful recognition.

**III.** Place the same fingerprint for five times. The blue light staying on for 2 seconds indicates successful registration. Flashing red light indicates registration failure; repeat the above steps to register again.

**IV.** Please repeat the above steps to register the second fingerprint.

**V.** Press and hold the reset hole with the pointer for more than 5 seconds. The blue light flash 5 times, indicating that all fingerprints cleared.

**VI.** Touch the fingerprint recognition area, the blue light will turn on and vibration will indicate success, once the fingerprint is recognized, the lock can be opened.

